
**User's
Manual**

**Model 810518801
SDH/SONET Frame Option**

Introduction

Thank you for your purchasing of this SDH/SONET Frame Option.

This option consists of the pattern editor application software (CD-ROM), designed for easy creation of OH patterns of SDH/SONET frame for the AQ2200-601 10Gbit/s BERT Module.

This manual describes the functions, operating procedures, and handling precautions necessary to operate the OH pattern editor.

Before starting operation of this option, thoroughly read this manual to use the product properly.

After reading this manual, always store it in a safe place where all concerned personnel can refer to it immediately.

This manual is useful if the operator have forgotten proper operation steps during operation.

For the functions, operating procedures, and handling precautions of the BERT module and frame controller, refer to their respective manuals.

Contents of the Package

- CD-ROM (for installation of the software): 1
- User's manual (this manual): 1

Notes

- The contents of this manual are subject to change without prior notice as a result of continuing improvements to the instrument's performance and functions.
The figures given in this manual may differ from those that actually appear on your screen.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without the permission of Yokogawa Electric Corporation is strictly prohibited.
- This software can be installed on more than one computer.
However, program patterns created by this software can run only on the AQ2200-601 10Gbit/s BERT Module to which the option has been implemented.
- Transfer or lending of this software to any third party is prohibited.
- Yokogawa Electric Corporation provides no guarantees other than for physical deficiencies found on the original disk upon opening the product package.
- Yokogawa Electric Corporation shall not be held responsible by any party for any losses or damage, direct or indirect, caused by the use or any unpredictable defect of the product.

Trademarks

- Microsoft, MS-DOS, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are trademarks of Adobe Systems Incorporated.
- For purposes of this manual, the TM and ® symbols do not accompany their respective trademark names or registered trademark names.
- Other product names are trademarks or registered trademarks of their respective holders.

Revisions

- 1st Edition: August 2005

Terms and Conditions of the Software License

Yokogawa Electric Corporation, a Japanese corporation (hereinafter called "Yokogawa"), grants permission to use this Yokogawa Software Program (hereinafter called the "Licensed Software") to the Licensee on the conditions that the Licensee agrees to the terms and conditions stipulated in Article 1 hereof.

You, as the Licensee (hereinafter called "Licensee"), shall agree to the following terms and conditions for the software license (hereinafter called the "Agreement") based on the use intended for the Licensed Software.

Please note that Yokogawa grants the Licensee permission to use the Licensed Software under the terms and conditions herein and in no event shall Yokogawa intend to sell or transfer the Licensed Software to the Licensee.

Licensed Software Name: SDH/SONET Frame Option (For AQ2200-601 10Gbit/s BERT Module)

Number of License: Free

Article 1 (Scope Covered by these Terms and Conditions)

- 1.1 The terms and conditions stipulated herein shall be applied to any Licensee who purchases the Licensed Software on the condition that the Licensee consents to agree to the terms and conditions stipulated herein.
- 1.2 The "Licensed Software" herein shall mean and include all applicable programs and documentation, without limitation, all proprietary technology, algorithms, and know-how such as a factor, invariant or process contained therein.

Article 2 (Grant of License)

- 2.1 Yokogawa grants the Licensee, for the purpose of single use, non-exclusive and non-transferable license of the Licensed Software with the license fee separately agreed upon by both parties.
- 2.2 The Licensee is, unless otherwise agreed in writing by Yokogawa, not entitled to copy, change, sell, distribute, transfer, or sublicense the Licensed Software.
- 2.3 The Licensed Software shall not be copied in whole or in part except for keeping one (1) copy for back-up purposes. The Licensee shall secure or supervise the copy of the Licensed Software by the Licensee itself with great, strict, and due care.
- 2.4 In no event shall the Licensee dump, reverse assemble, reverse compile, or reverse engineer the Licensed Software so that the Licensee may translate the Licensed Software into other programs or change it into a man-readable form from the source code of the Licensed Software. Unless otherwise separately agreed by Yokogawa, Yokogawa shall not provide the Licensee the source code for the Licensed Software.
- 2.5 The Licensed Software and its related documentation shall be the proprietary property or trade secret of Yokogawa or a third party which grants Yokogawa the rights. In no event shall the Licensee be transferred, leased, sublicensed, or assigned any rights relating to the Licensed Software.
- 2.6 Yokogawa may use or add copy protection in or onto the Licensed Software. In no event shall the Licensee remove or attempt to remove such copy protection.
- 2.7 The Licensed Software may include a software program licensed for re-use by a third party (hereinafter called "Third Party Software", which may include any software program from affiliates of Yokogawa made or coded by themselves.) In the case that Yokogawa is granted permission to sublicense to third parties by any licensors (sub-licensor) of the Third Party Software pursuant to different terms and conditions than those stipulated in this Agreement, the Licensee shall observe such terms and conditions of which Yokogawa notifies the Licensee in writing separately.
- 2.8 In no event shall the Licensee modify, remove or delete a copyright notice of Yokogawa and its licensor contained in the Licensed Software, including any copy thereof.

Article 3 (Restriction of Specific Use)

- 3.1 The Licensed Software shall not be intended specifically to be designed, developed, constructed, manufactured, distributed or maintained for the purpose of the following events:
 - a) Operation of any aviation, vessel, or support of those operations from the ground;;
 - b) Operation of nuclear products and/or facilities;;
 - c) Operation of nuclear weapons and/or chemical weapons and/or biological weapons; or
 - d) Operation of medical instrumentation directly utilized for humankind or the human body.
- 3.2 Even if the Licensee uses the Licensed Software for the purposes in the preceding Paragraph 3.1, Yokogawa has no liability to or responsibility for any demand or damage arising out of the use or operations of the Licensed Software, and the Licensee agrees, on its own responsibility, to solve and settle the claims and damages and to defend, indemnify or hold Yokogawa totally harmless, from or against any liabilities, losses, damages and expenses (including fees for recalling the Products and reasonable attorney's fees and court costs), or claims arising out of and related to the above-said claims and damages.

Article 4 (Warranty)

- 4.1 The Licensee shall agree that the Licensed Software shall be provided to the Licensee on an "as is" basis when delivered. If defect(s), such as damage to the medium of the Licensed Software, attributable to Yokogawa is found, Yokogawa agrees to replace, free of charge, any Licensed Software on condition that the defective Licensed Software shall be returned to Yokogawa's specified authorized service facility within seven (7) days after opening the Package at the Licensee's expense. As the Licensed Software is provided to the Licensee on an "as is" basis when delivered, in no event shall Yokogawa warrant that any information on or in the Licensed Software, including without limitation, data on computer programs and program listings, be completely accurate, correct, reliable, or the most updated.
- 4.2 Notwithstanding the preceding Paragraph 4.1, when third party software is included in the Licensed Software, the warranty period and terms and conditions that apply shall be those established by the provider of the third party software.
- 4.3 When Yokogawa decides in its own judgement that it is necessary, Yokogawa may from time to time provide the Licensee with Revision upgrades and Version upgrades separately specified by Yokogawa (hereinafter called "Updates").
- 4.4 Notwithstanding the preceding Paragraph 4.3, in no event shall Yokogawa provide Updates where the Licensee or any third party conducted renovation or improvement of the Licensed Software.
- 4.5 THE FOREGOING WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES OF QUALITY AND PERFORMANCE, WRITTEN, ORAL, OR IMPLIED, AND ALL OTHER WARRANTIES INCLUDING ANY IMPLIED WARRANTIES OF

MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED BY YOKOGAWA AND ALL THIRD PARTIES LICENSING THIRD PARTY SOFTWARE TO YOKOGAWA.

- 4.6 Correction of nonconformity in the manner and for the period of time provided above shall be the Licensee's sole and exclusive remedy for any failure of Yokogawa to comply with its obligations and shall constitute fulfillment of all liabilities of Yokogawa and any third party licensing the Third Party Software to Yokogawa (including any liability for direct, indirect, special, incidental or consequential damages) whether in warranty, contract, tort (including negligence but excluding willful conduct or gross negligence by Yokogawa) or otherwise with respect to or arising out of the use of the Licensed Software.

Article 5 (Infringement)

- 5.1 If and when any third party should demand injunction, initiate a law suit, or demand compensation for damages against the Licensee under patent right (including utility model right, design patent, and trade mark), copy right, and any other rights relating to any of the Licensed Software, the Licensee shall notify Yokogawa in writing to that effect without delay.
- 5.2 In the case of the preceding Paragraph 5.1, the Licensee shall assign to Yokogawa all of the rights to defend the Licensee and to negotiate with the claiming party. Furthermore, the Licensee shall provide Yokogawa with necessary information or any other assistance for Yokogawa's defense and negotiation. If and when such a claim should be attributable to Yokogawa, subject to the written notice to Yokogawa stated in the preceding Paragraph 5.1, Yokogawa shall defend the Licensee and negotiate with the claiming party at Yokogawa's cost and expense and be responsible for the final settlement or judgment granted to the claiming party in the preceding Paragraph 5.1.
- 5.3 When any assertion or allegation of the infringement of the third party's rights defined in Paragraph 5.1 is made, or when at Yokogawa's judgment there is possibility of such assertion or allegation, Yokogawa will, at its own discretion, take any of the following countermeasures at Yokogawa's cost and expense.
- a) To acquire the necessary right from a third party which has lawful ownership of the right so that the Licensee will be able to continue to use the Licensed Software;
 - b) To replace the Licensed Software with an alternative one which avoids the infringement; or
 - c) To remodel the Licensed Software so that the Licensed Software can avoid the infringement of such third party's right.
- 5.4 If and when Yokogawa fails to take either of the countermeasures as set forth in the preceding subparagraphs of Paragraph 5.3, Yokogawa shall indemnify the Licensee only by paying back the price amount of the Licensed Software which Yokogawa has received from the Licensee. THE FOREGOING PARAGRAPHS STATE THE ENTIRE LIABILITY OF YOKOGAWA AND ANY THIRD PARTY LICENSING THIRD PARTY SOFTWARE TO YOKOGAWA WITH RESPECT TO INFRINGEMENT OF THE INTELLECTUAL PROPERTY RIGHTS INCLUDING BUT NOT LIMITED TO, PATENT AND COPYRIGHT.

Article 6 (Liabilities)

- 6.1 If and when the Licensee should incur any damage relating to or arising out of the Licensed Software or service that Yokogawa has provided to the Licensee under the conditions herein due to a reason attributable to Yokogawa, Yokogawa shall take actions in accordance with this Agreement. However, in no event shall Yokogawa be liable or responsible for any special, incidental, consequential and/or indirect damage, whether in contract, warranty, tort, negligence, strict liability, or otherwise, including, without limitation, loss of operational profit or revenue, loss of use of the Licensed Software, or any associated products or equipment, cost of capital, loss or cost of interruption of the Licensee's business, substitute equipment, facilities or services, downtime costs, delays, and loss of business information, or claims of customers of Licensee or other third parties for such or other damages. Even if Yokogawa is liable or responsible for the damages attributable to Yokogawa and to the extent of this Article 6, Yokogawa's liability for the Licensee's damage shall not exceed the price amount of the Licensed Software or service fee which Yokogawa has received. Please note that Yokogawa shall be released or discharged from part or all of the liability under this Agreement if the Licensee modifies, remodels, combines with other software or products, or causes any deviation from the basic specifications or functional specifications, without Yokogawa's prior written consent.
- 6.2 All causes of action against Yokogawa arising out of or relating to this Agreement or the performance or breach hereof shall expire unless Yokogawa is notified of the claim within one (1) year of its occurrence.
- 6.3 In no event, regardless of cause, shall Yokogawa assume responsibility for or be liable for penalties or penalty clauses in any contracts between the Licensee and its customers.

Article 7 (Limit of Export)

Unless otherwise agreed by Yokogawa, the Licensee shall not directly or indirectly export or transfer the Licensed Software to any countries other than those where Yokogawa permits export in advance.

Article 8 (Term)

This Agreement shall become effective on the date when the Licensee receives the Licensed Software and continues in effect unless or until terminated as provided herein, or the Licensee ceases using the Licensed Software by itself or with Yokogawa's thirty (30) days prior written notice to the Licensee.

Article 9 (Injunction for Use)

During the term of this Agreement, Yokogawa may, at its own discretion, demand injunction against the Licensee in case that Yokogawa deems that the Licensed Software is used improperly or under severer environments other than those where Yokogawa has first approved, or any other condition which Yokogawa may not permit.

Article 10 (Termination)

Yokogawa, at its sole discretion, may terminate this Agreement without any notice or reminder to the Licensee if the Licensee violates or fails to perform this Agreement. However, Articles 5, 6, and 11 shall survive even after the termination.

Article 11 (Jurisdiction)

Any dispute, controversies, or differences between the parties hereto as to interpretation or execution of this Agreement shall be resolved amicably through negotiation between the parties upon the basis of mutual trust. Should the parties fail to agree within ninety (90) days after notice from one of the parties to the other, both parties hereby irrevocably submit to the exclusive jurisdiction of the Tokyo District Court (main office) in Japan for settlement of the dispute.

Terms and Conditions of the Software License

Article 12 (Governing Law)

This Agreement shall be governed by and construed in accordance with the laws of Japan. The Licensee expressly agrees to waive absolutely and irrevocably and to the fullest extent permissible under applicable law any rights against the laws of Japan which it may have pursuant to the Licensee's local law.

Article 13 (Severability)

In the event that any provision hereof is declared or found to be illegal by any court or tribunal of competent jurisdiction, such provision shall be null and void with respect to the jurisdiction of that court or tribunal and all the remaining provisions hereof shall remain in full force and effect.

How to Use This Manual

Structure of This Manual

This user's manual consists of the following chapters.

Chapter	Title	Description
1	Description of Functions	This chapter provides an overview of the software and lists its main functions (file and editing functions).
2	Setup	This chapter describes the system requirements of the software, and lists the procedures for installing and uninstalling the software.
3	Operating Procedures	Provides the procedures for creating OH patterns using the software.
4	Loading Pattern Data	This chapter describes mounting to a frame controller and loading created OH pattern data.
	Appendix	Lists the initial setting values.

Table of contents

1

2

3

4

App

Introduction	i
Terms and Conditions of the Software License	ii
How to Use This Manual	v

Chapter 1 Functional Description

1.1 Overview	1-1
1.2 Function Overview	1-2

Chapter 2 Setup

2.1 System Environment	2-1
2.2 Installation/Uninstallation	2-2

Chapter 3 Operating Procedures

3.1 Flow of Operation	3-1
3.2 Screen Structure	3-2
3.3 Starting the Application	3-3
3.4 Explanation of Each Screen	3-4
3.5 Explanation of Each Operation Mode	3-5
3.6 File Operation	3-8
3.7 Edit Operation	3-12
3.8 Setup Operation	3-17
3.9 Explanation of Other Functions	3-18

Chapter 4 Loading Pattern Data

4.1 Preparation	4-1
4.2 Loading a File	4-2

Appendix

Appendix 1 Initial Setting Values	Appendix-1
---	------------

1.1 Overview

This application software is designed for easy creation of OH patterns of SDH/SONET frame for AQ2200-601 10Gbit/s BERT Module, and runs on Windows PC.

Major Features

- OH pattern editor for AQ2200-601 10Gbit/s BERT Module
- Runs on Windows (98SE/ME/2000/XP SP1) and enables creation of OH pattern data.
- Created pattern data can be stored in the compact flash card.
- The pattern data stored in the compact flash card can be imported to the AQ2200 Series Frame Controller equipped with the AQ2200-601 10Gbit/s BERT Module, by inserting the compact flash card into the frame controller.
- This application software is designed for easy creation of OH pattern data for AQ2200-601 10Gbit/s BERT Module SDH/SONET frames, and runs on Windows PC.
- Easily create OH patterns for STM-0, OC-1/STM-1, OC-3/STM-64, and OC-192 units.

1.2 Function Overview

(1) File Function

The file function is used to load/save a file or exit this application.

The file function setting items are shown below.

- Items available for SONET/SDH and Program modes
 - Load the initial value of the OH pattern (SDH frame) (Init: SDH)
 - Load the initial value of the OH pattern (SONET frame) (Init: SONET)
 - Opening a file (Open)
 - Overwriting a file (Save)
 - Specifying a file name and saving the data in that file (Save As)
 - Exiting the application (Exit)

The file functions can be set using the menu (File menu) and shortcut keys.

For details, see Section 3.6.

(2) Edit Function

The edit function is used to create/edit OH pattern data.

The edit function setting items are shown below.

- Undoing an operation (Undo)
- Redoing an operation (Redo)
- Copy (Copy)
- Paste (Paste)
- Selecting all SOH/TOH (Select All)
- Edit mode (Edit Unit)

The edit functions can be set using the menu (Edit menu) and shortcut keys (except for Select xx).

For details, see Section 3.7.

2.1 System Environment

Hardware Requirements

This software runs under the following environment.

Item	Condition
Personal computer	
CPU	Pentium III 500MHz or higher
Hard disk capacity	500MB or more recommended
Memory capacity	256MB or higher
CD-ROM drive	
Monitor	Resolution 800 × 600 dots or higher, 256 colors or higher
Operating system	English/Japanese version *1 Windows 98SE, Windows ME, Windows 2000, Windows XP SP1

*1: If this application software is installed on Windows PC (Japanese version), texts will be displayed in Japanese.

Note
This manual explains the operating method when this application software is used with English Windows 2000.

2.2 Installation/Uninstallation

Operating Procedures

Installation

1. Start the PC.
2. Insert the attached CD-ROM containing this application software into the CD-ROM drive on the PC.
3. Double-click the “**Setup.Exe**” icon in the OHEdit folder of the CD-ROM drive.



The installer will start and setup will begin.

4. Follow the instructions displayed on the screen to perform installation.
5. When installation is complete, a shortcut to the following submenu will be created: Windows [**Start**] button - [**Programs**] - [**OHEdit**] - [**OHEdit**].

Uninstallation

1. From the Windows [**Start**] button, select [**Settings**] - [**Control Panel**] – [**Add or Remove Programs**].
2. Select “**OHEdit**” from the program list, and click [Remove].
3. Follow the instructions displayed on the screen.

Explanation

● Installation folder

This application software will be installed in the following folder.
C:\Program Files\YOKOGAWA\OHEdit

● Changing the installation folder

The installation folder can be changed while “**Select Installation Folder**” is displayed during installation.


● Installation files

The following files will be installed.

- OHEdit.exe: Executable file
- sonet_init.dat: InitialOH data file for SONET
- sdh_init.dat: InitialOH data file for SDH

3.1 Flow of Operation


Operation Flow



() indicates the section to be referred to.

3.2 Screen Structure

The screen structure of this application software is shown below.




3.3 Starting the Application

Operating Procedures

1. From the Windows **[Start]** button, select **[Programs]** - **[OHEdit]** - **[OHEdit]**, and then click it.



Over HEAD Editor for 10Gbit/s BERT (hereafter called OHEdit) will start.



Explanation


- When starting the application, the initial settings are read. For the initial settings, see Appendix 1.
- For details regarding exiting the application, see Section 3.6 (5) "Exiting the Application (Exit)".

Note

To load or save a file, insert the PC card adapter for CF (with the compact flash card installed) into the PC card slot on the PC.

3.4 Explanation of Each Screen

SONET/SDH Mode




Name	Function
Title bar	Displays the file name and the title name of this application. If no file name is set, "Untitled" will be displayed. An asterisk (*) is displayed at the end of the file during edit. For details, see Section 3.9 (1).
Menu	Displays each operation item as a command. For details, see Section 3.6.
Status bar	Displays the coordinates of the cursor position and the byte position of the data. For details, see Section 3.9 (2).
Mode display	Displays the OH edit mode. SONET OC-1/OC-3/OC-192/SDH STM0/STM1/STM64 For details, see Sections 3.5.
Frame No.	The frame No. can be displayed/changed (1: PPG, 2: ED). For details, see Sections 3.5.
OC-n#/STMn# No.	The OC-n# No. (screen No.) can be displayed/changed when SONET OC-1 or OC-3 has been selected as the operation mode, and the STMn# No. (screen No.) can be displayed/changed when SDH STM0 or STM1 has been selected. They will not be displayed if SONET OC-192, SDH STM64 has been selected as the operation mode. For details, see Section 3.5.
TOH/SOH edit area	TOH data can be displayed/changed when SONET has been selected as the operation mode, and the SOH data can be displayed/changed when SDH has been selected. For details, see Section 3.5.
Column button	Used to select a column or consecutive columns. For details, see Section 3.7 (4).
Row button	Used to select a row or consecutive rows. For details, see Section 3.7 (4).

3.5 Explanation of Each Operation Mode

(1) SONET OC-1 Mode / SDH STM0 Mode

In SONET OC-1 and SDH STM-0 modes, a 10-Gbps frame can be edited in 192 blocks in OC-1 unit / STM0 unit.



- **Frame No. (Frame#)** Displays the frame No. of the currently displayed data. The frame No. can be changed between 1 (PPG) and 2 (ED). To change it, enter the desired frame No. in the "Frame#" field and press the [Enter] key or select it by pressing the [▲] and [▼] buttons.
- **STM-0# No./OC-1# No. (STM-0#/OC-1#)** Displays the screen No. of the currently displayed data. The screen No. can be changed between 1 and 192. To change it, enter the desired screen No. in the "STM-0#/OC-1#" field and press the [Enter] key or select it by pressing the [▲] and [▼] buttons.
- **SOH/TOH edit area** Used to edit SOH/TOH data. Data of 3 columns × 9 rows (= 27 bytes) can be edited. Enter data (HEX format) in the SOH/TOH edit area directly.


[illegible]

SDH STM1 Mode

- **Frame No. (Frame#)** Displays the frame No. of the currently displayed data. The frame No. can be changed between 1 (PPG) and 2 (ED). To change it, enter the desired frame No. in the "Frame#" field and press the [Enter] key or select it by pressing the [▲] and [▼] buttons.
- **STM-1# No./OC-3# No. (STM-1#/OC-3#)** Displays the screen No. of the currently displayed data. The screen No. can be changed between 1 and 64. To change it, enter the desired screen No. in the "STM-1#/OC-3#" field and press the [Enter] key or select it by pressing the [▲] and [▼] buttons.
- **SOH/TOH edit area** Used to edit SOH/TOH data. Data of 9 columns × 9 rows (= 81 bytes) can be edited. Enter data (HEX format) in the SOH/TOH edit area directly.

(3) SDH STM-64 Mode / SONET OC-192 Mode

In SDH STM-64/SONET OC-192 modes, one 10-Gbps frame can be edited as it is in STM-1/OC-192 unit.



- Frame No. (Frame#) Displays the frame No. of the currently displayed data. The frame No. can be changed between 1 (PPG) and 2 (ED). To change it, enter the desired frame No. in the "Frame#" field and press the [Enter] key or select it by pressing the [▲] and [▼] buttons.
- Column No. (column) Displays the horizontal axis offset for column 1 in the SOH/TOH and PayLoad edit areas. The column No. can be changed between 1 and 568 in the case of SOH/TOH, and 1 and 16,676 in the case of Payload. To change it, enter the desired column No. in the "column" field and press the [Enter] key or select it by pressing the [▲] and [▼] buttons. The column No. changes with movement of the scroll bar.
- SOH/TOH edit area Used to edit SOH/TOH data. Data of 32 columns × 9 rows (= 288 bytes) can be edited. Enter data (HEX format) in the SOH/TOH edit area directly.

3.6 File Operation

(1) Creating SDH Overhead Initial Values (Init:SDH)

Operating Procedures

1. Choose **File > Init:SDH**.
2. SDH overhead initial values are created.

Explanation

- SDH overhead initial value data file
 - sdh_init.dat: Created during installation (for details, see section 2-2 below).
- SDH overhead initial value data
 - Described below in units of 64-byte blocks. Each square in the diagram represents a block (64 bytes) of data. Values other than 00 are placed in dark colored blocks.

Structure of Overhead Data

1	2	3	4	5	6	7	8	9
10	...						18	
19							27	
28	29	30	31	32	33	36		
37	...						45	
46							54	
55	...						63	
64							72	
73	...						81	

Block 1	F6	(all 64 bytes)
Block 2	F6	(all 64 bytes)
Block 3	F6	(all 64 bytes)
Block 4	28	(all 64 bytes)
Block 5	28	(all 64 bytes)
Block 6	28	(all 64 bytes)
Block 7	01-40	
Block 8	AA	
Block 9	AA	
Block 10-27	00	(all in this range)
Block 28	68	(first byte only)
	9B	(remaining 63 bytes)
Block 29	9B	(all 64 bytes)
Block 30	9B	(all 64 bytes)
Block 31	FF	(all 64 bytes)
Block 32	FF	(all 64 bytes)
Block 33	FF	(all 64 bytes)
Block 34-81	00	(all in this range)

(2) Creating SONET Overhead Initial Values (Init:SONET)

Operating Procedures

1. Choose **File > Init:SONET** from the **menu**.
2. SONET overhead initial values are created.

Explanation

- SONET overhead initial value data file
 - sonet_init.dat: Created during installation (for details, see section 2-2 below).
- SONET overhead initial value data
 - Described below in units of 64-byte blocks. Each square in the diagram represents a block (=64 bytes) of data. Values other than 00 are placed in dark colored blocks.

Structure of Overhead Data

1	2	3	4	5	6	7	8	9		
10	...							18		
19								27		
28	29	30	31	32	33			36		
37	...							45		
46								54		
55	...							63		
64								72		
73	...							81		

Block 1	F6	(all 64 bytes)
Block 2	F6	(all 64 bytes)
Block 3	F6	(all 64 bytes)
Block 4	28	(all 64 bytes)
Block 5	28	(all 64 bytes)
Block 6	28	(all 64 bytes)
Block 7	01-40	
Block 8	41-48	
Block 9	80-C0	
Block 10-27	00	(all in this range)
Block 28	60	(first byte only)
	93	(remaining 63 bytes)
Block 29	93	(all 64 bytes)
Block 30	93	(all 64 bytes)
Block 31	FF	(all 64 bytes)
Block 32	FF	(all 64 bytes)
Block 33	FF	(all 64 bytes)
Block 34-81	00	(all in this range)

(3) Opening a File (Open)


Operating Procedures

1. Select **[File] - [Open...]** from the **menu bar**.
The **Open file selection dialog box** will appear.
2. Select the data file to be imported, and click <Open>.
The imported data will be displayed in the SOH/TOH edit area.

If you are not going to import the data, click <Cancel>.
The current edit screen will reappear.

Explanation

- File format that can be imported
Data in dat format can be imported.
"file name".dat
- When a file in unknown format is selected
The following **alarm dialog box** will appear, informing you that the data file cannot be imported.
Click <OK> to return to the current edit screen.



"drive name\folder name\file name" file cannot be opened.

(4) Overwriting a File (Save)

Operating Procedures

<When a file name has been set for the currently edited data>

1. Select **[File] - [Save]** from the **menu bar**.
The data will be overwritten and the current edit screen will reappear.

<When no file name has been set for the currently edited data>

1. Select **[File] - [Save]** from the **menu bar**.
The **Save file selection dialog box** will appear.
2. Enter a file name and click <Save>.
The data will be saved to the specified file and the current edit screen will reappear.

If you are not going to save the data, click <Cancel>.
The current edit screen will reappear.

Explanation

- File save format
The data is saved in dat format.
"file name".dat

(5) Specifying a File Name and Saving the Data in That File (Save As)**Operating Procedures**

1. Select **[File] - [SaveAs...]** from the **menu bar**.
The **Save file selection dialog box** will appear.
 2. Enter a file name and click <Save>.
The data will be saved to the specified file and the current edit screen will reappear.
- If you are not going to save the data, click <Cancel>.
The current edit screen will reappear.

Explanation


- File save format
The data is saved in dat format.
"file name".dat

(6) Exiting the Application (Exit)**Operating Procedures****<When the data has been saved>**

1. Select **[File] - [Exit]** from the **menu bar**.
The application will be exited.

<When the data has not been saved>

1. Select **[File] - [Exit]** from the **menu bar**.
The following **alarm dialog box** asking you whether to save the currently edited data will appear.



2. To save the data and exit the application, click <Yes>.
To exit the application without saving the data, click <No>.
To return to the edit screen without saving the data, click <Cancel>.

Explanation

- When <Yes> is clicked
 - If a file name has been set, the data will be overwritten and saved.
 - If no file name has been set, the **Save file selection dialog box** will appear. Enter a file name and click <Save>. The data will be saved.

Note

Commercially available CF adapter required when writing to CF card.

3.7 Edit Operation


(1) Entering data

Operating Procedures

1. In the SOH/TOH edit area, locate the cursor at the position where you want to enter data.
2. Enter the desired character ("0" to "F").
When entry of the upper byte is complete, the entered character will be displayed in blue.
3. Next, enter the desired character ("0" to "F") for the lower byte.
When entry of the lower byte is complete, the data will be confirmed and the cursor will move to the next data position.
4. To continue to enter more data, repeat steps 2 to 3.

Explanation

- Data can be entered one byte at a time.
 - If the lower byte data has not been entered even though the upper byte data has, the characters will be displayed in blue indicating that the data cannot be confirmed.
 - If you press the [Enter] key with the upper byte entered, the data consisting of the upper byte and the currently displayed lower byte data will be confirmed.
 - If you press the [Esc] key with the upper byte entered, the upper byte data will be canceled.
- Characters "0" to "F" (HEX) can be entered.
If any other characters are entered, they will be ignored and the contents of the screen will not be changed.
- Graphical explanation of data entry procedure



(2) Undoing an Operation (Undo)

Operating Procedures

1. Select **[Edit] - [Undo]** from the **menu bar**.
The previous contents of the currently edited data will be restored.

Explanation

- Conditions for Undo operation
Undo is effective just after data input, paste and fill edit operations.
Undo will be invalid (i.e. displayed in gray) before edit and just after undo, indicating that Undo cannot be selected.
- Recorded number of Undo operations
Only one undo operation is recorded.

(3) Redoing an Operation (Redo)

Operating Procedures

1. Select **[Edit] - [Redo]** from the **menu bar**.
The contents of the currently edited data effective just before the last undo will be restored.

Explanation

- Conditions for Redo operation
Redo can only be selected just after undo is performed.
Redo will be invalid (i.e. displayed in gray) if edit operation is performed after undo, indicating that Undo cannot be selected.
- Recorded number of Redo operations
Only one redo operation is recorded.

(4) Copy & Paste

Operating Procedures

1. In the SOH/TOH edit area, select the area of the data (1 byte or more) to be copied.
2. Select **[Edit] - [Copy]** from the **menu bar**.
3. Select the area (1 byte or more) to which the selected data is to be pasted.
4. Select **[Edit] - [Paste]** from the **menu bar**.
The copied data will be pasted into the selected area.

Explanation

- Selecting an area
Area selection items include column, row, and All.
The selected area will be highlighted.
- Column
The specified column is selected.
If you click the mouse with the focus located on a column button (in the SOH/TOH edit area), all the data present in that column will be selected.
If you select a column and drag the mouse or press a cursor key + [Shift] key, all the data present in the selected column area will be selected.
- Row
The specified row is selected.
If you click the mouse with the focus located on a row button (at the left of the SOH/TOH edit area), all the data present in that row will be selected.
If you select a row and drag the mouse or press a cursor key + [Shift] key, all the data present in the selected row area will be selected.
- All
The SOH/TOH edit area is selected.
For details, see Section 3.7 (5).
- Canceling the selected area
If you press the [Esc] key while an area is currently selected, the selected area will be cancelled and only the data at the selected position will be selected.
If you click the mouse while an area is currently selected, the selected area will be cancelled and only the data at the clicked position will be selected.
The selected area will also be cancelled if the focus moves into another edit area.
- Copy operation
If you execute a new copy after executing a copy, the old copied data will be deleted.
The data inside the copy area will be kept irrespective of the selected area's shape (column, row, and All).

- Paste operation
 - When no data area has been selected

If only one data is specified without selecting an area, the content of the copied data will be pasted starting from the specified position up to the copy size.
 - When a data area has been selected

If a data area has been selected, the copied data will be pasted into that area.
 - If the selected area's shape (column, row, and All) of the copy source differs from that of the paste destination, the data will be pasted serially.
 - When the selected area of the copy source differs from that of the paste destination
 - Copy source > Paste destination


If the copy data is larger than the selected paste area, the copied data will be pasted, starting from the beginning of the data up to the selected area size.
 - Copy destination > Paste source

If the selected paste area is larger than the copied data, the copied data will be pasted repeatedly until the entire selected area is filled with the data.

(5) Selecting All Data (Select All)

Operating Procedures

- 1. Select [Edit] - [Select All] from the menu bar.
- 2. The Edit area will be highlighted indicating that it is currently selected.



Explanation

- The selected area contains parts that are displayed when scrolled.

3.8 Setup Operation

Help Menu (Help)

Operating Procedures

1. Select **[Help] - [About...]** from the **menu bar**.
The **About dialog box** will appear.



2. Click **<OK>** to return to the previous screen.

Explanation

- The About dialog box shows the version information of this application.

3.9 Explanation of Other Functions

(1) Title Bar

Displays the file name and the title name of this application.

If a file name has been set, "file name.dat" will be displayed.


If no file name is set, "Untitled" will be displayed.

An asterisk (*) is displayed at the end of the file during edit.


- When the file name is "STM-1_SOH.dat" and the file is not currently edited

A screenshot of a title bar with a blue background. On the left, there is a small icon with the letters 'O' and 'E' in blue and red. To the right of the icon, the text 'STM-1_SOH.dat - Over Head Editor for 10Gbit/s BERT' is displayed in white.


- When the file name is "STM-1_SOH.dat" and the file is currently edited

A screenshot of a title bar with a blue background. On the left, there is a small icon with the letters 'O' and 'E' in blue and red. To the right of the icon, the text 'STM-1_SOH.dat* - Over Head Editor for 10Gbit/s BERT' is displayed in white.

- When no file name is set and the file is not currently edited


A screenshot of a title bar with a blue background. On the left, there is a small icon with the letters 'O' and 'E' in blue and red. To the right of the icon, the text 'Untitled - Over Head Editor for 10Gbit/s BERT' is displayed in white.

- When no file name is set and the file is currently edited

A screenshot of a title bar with a blue background. On the left, there is a small icon with the letters 'O' and 'E' in blue and red. To the right of the icon, the text 'Untitled* - Over Head Editor for 10Gbit/s BERT' is displayed in white.

(2) Status Bar

Displays the coordinates of the data located at the cursor position and the byte position of that data (relative position from the beginning of the data).



Display content of the status bar

Area Selection	Data Coordinates	Byte Position
Only one data is selected	"X=x Y=y" Displays the coordinate (x, y) of the cursor position in TOH/SOH area.	Displays the byte position of the selected data (from the beginning of the frame).
A to B is selected	"(x1, y1) - (x2, y2)" Displays the coordinate (x, y) of the cursor position in TOH/SOH area.	Displays the byte position of the selected data (from the beginning of the frame).
One column is selected in TOH/SOH	"column x" Displays the coordinate x of the selected column in TOH/SOH area.	None
Column selection is made in TOH/SOH	"column (x1) - (x2)" Displays the coordinate x1, x2 of the selected column area in TOH/SOH area.	None
One row is selected in TOH/SOH	"row y" Displays the coordinate y of the selected row in TOH/SOH area.	None
Row selection is made in TOH/SOH	"row (y1) - (y2)" Displays the coordinate y1, y2 of the selected row area in TOH/SOH area.	None
TOH/SOH is selected	"Select TOH" / "Select SOH"	None
All is selected	"Select All"	None

3.9 Explanation of Other Functions

- 1) In the case of “A to B”, the contents in the “Data coordinates” and “Byte position” fields differ depending on the selection method.

Data coordinates: (Start position x1, y1) – (End position x2, y2)

Byte position: Displays the byte position of the end position.

Example 1) When selecting (1,1) to (5,1) in STM-1/OC-3 using the “A to B” selection method

Data coordinates: (1,1) to (5,1)

Byte position: 257

Example 2) When selecting (5,1) to (1,1) in STM-1/OC-3 using the “A to B” selection method

Data coordinates: (5,1) to (1,1)

Byte position: 1

- 2) In the case of column/row selection, the content in the “Data coordinates” field differs depending on the selection method.

Data coordinates: For column (Start position x1) – (End position x2)

For row (Start position y1) – (End position y2)

Example 1) When selecting columns (1) to (5) in STM-1/OC-3

Data coordinates: PayLoad columns (1) to (5)

Example 2) When selecting columns (5) to (1) in STM-1/OC-3

Data coordinates: PayLoad columns (5) to (1)

* In the above examples, the selected area is the same, though the display contents differ. Therefore, file operation and copy & paste operation have the same results.

(3) Context Menu

If you right-click with the cursor located in an edit area, a context menu will appear. It contains the same items as the [Edit] menu.

<u>U</u> ndo	Ctr+Z
<u>R</u> edo	Shift+Ctrl+Z
<u>C</u> opy	Ctrl+C
<u>P</u> aste	Ctrl+V
Select <u>A</u> ll	Ctrl+A
<u>E</u> dit Unit	▶

4.1 Preparation

(1) Installing the Compact Flash Card

Install the compact flash card containing the created pattern data into the AQ2201/AQ2202 Frame Controller equipped with the AQ2200-601 10Gbit/s BERT Module.

Note

The compact flash card can be inserted/removed even if the power to the frame controller is currently ON.

However, do not remove it while the BERT application is in progress.

(2) Starting the BERT Application

Press the [APPLI] key on the front panel of the frame controller to start the BERT application.

Note

For details, see Section 5.4 in the AQ2200-601 10Gbit/s BERT Module's Users Manual (IM810518801-01E).

4.2 Loading a File

Load a pattern data file stored in the compact flash card to the BERT Module.

Operating Procedures

BERT APPLICATION			
00:00:00:10 Log			
System clock err	Syn-los	0	Start mes
Err on CDR ulk	Err-ent	0	
Output			Stop mes
PPG ED DAT MES UTL			
File load/save	Logging	OFF	Error add
	Logging period	1sec	
	Logging mode	All	
			Signal output
			Information

1. With the [CHAN] or [FRAME] key, select UTL for the current module.
2. With the [▲], [▼], [◀], or [▶] key, move the cursor so that "File load/save" becomes the current parameter and press the [ENTER] key.
3. The File load/save popup screen will appear.
With the [▲] or [▼] key, move the cursor to any of **Parameter load**, **Parameter save**, and **Long prog load**, and press the <OK> or [ENTER] key, and the **File select screen** will appear.


(1) Move the cursor to "File load/save" and press the [ENTER] key.

BERT APPLICATION			
00:00:00:00 Log			
System clock err	Syn-los	Current	OK
Err on CDR ulk	Err-ent	Current	
Output		0	Cancel
PPG ED DAT MES UTL			
File lo	File load/save		
	Parameter save		
	Long prog load		
	SOH/TOH load		

(3) Press the <OK> or [ENTER] key, and the File select screen will appear.

(2) With the [▲] or [▼] key, select any of **Parameter load**, **Parameter save**, and **SOH/TOH load**.

Popup Screen




File Select Screen

4. On the **File select** screen, move the cursor to the corresponding file in the **File List** using the [▲] or [▼] key, and press the <Select> or [ENTER] key.
5. The **Load Question** popup screen will appear. Press the <Yes> or [ENTER] key, and the selected file will be loaded.

(5) Press the <Select> or [ENTER] key, and the Load Question popup screen will appear.

(4) With the [▲] or [▼] key, move the cursor to the corresponding file in the **File List**.



Question Popup Screen

(6) Press the <Yes> or [ENTER] key, and the selected file will be loaded.

Note

For details, see Section 5.5 in the AQ2200-601 10Gbit/s BERT Module's Users Manual (IM810518801-01E).

Appendix

Appendix 1 Initial Setting Values

Setting Item	Initial Value	Remarks
Screen edit mode ("Edit Unit")	STM-1/OC-3	
Frame No. ("Frame#")	1	
Screen No. ("OC-n# / STMn#")	1	